



Transmission Stop Leak

Typical Specifications

Engine Armour Transmission Stop Leak helps to stop and prevent transmission seal leaks. Helps to reduce friction and wear in the transmission, cleans and helps prevent harmful formation of sludge and varnish. It can recondition old dry transmission seals, help smooth a rough shifting transmission, and help the transmission run cooler and last longer.

Engine Armour Transmission Stop Leak mixes with all factory approved transmission fluids.

Typical Inspection Data:

API Gravity	30.8
Viscosity cSt	
@ 100 C	5.0
Color	RED
Flash Point C	190
Pour Point C	< -40C
Foam Tendency	Pass

The data presented in this specification sheet are believed to be accurate; however, Engine Armour shall not be liable for its content and makes no warranty with respect thereto.